

Little Green Tent

Dimensions

Assembled Height (cm)

105.0

Assembled Depth (cm)

113.0

Assembled Width (cm)

110.0

Extra Dimensions

Window - 14cm x 14cm. Door opening - approx. 84cm high x 110cm wide. Internal measurements of pockets - 30cm wide x 25cm deep

manufacturer's assembly instructions in detail.

A



vertical
beams x4

B



horizontal
beams x3

C



end
screws x6

D




fabric
cover x1

HARDWARE SUPPLIED


WARNING!

- Due to small parts, the Minka House should be assembled by an adult.
- Keep away from fire.




Recommended age is 18 months +

1




Lay out 4x vertical beams (A) as shown

2




Thread the 2x vertical beams which were laid out through the tent cover top corner as shown on the picture, then make them stable. Thread 1x horizontal beam (B) through the top, gather each side in the position shown in the above picture with 2x bamboo screws (C).

3



Thread 2x horizontal beam (B) through the bottom seam of the fabric, secure them with bamboo screw (C) as shown

4



All done. Enjoy it!