

# Little White Teepee

**Assembled Height (cm)**

160.0

**Assembled Depth (cm)**

110.0


**Assembled Width (cm)**

110.0

## Extra Dimensions


Door opening approx. 70cm high.

Thank you for purchasing Henley Teepee. Please follow the manufacturer's assembly instructions in detail.




**WARNING!**

- Due to small parts, the Henley Teepee should be assembled by an adult.
- Keep away from fire.




Recommended age is 12 months +

# 1




# 2



To begin assembly, connect wooden poles (B)(D) and (C) together with the plastic tube (A) as shown. Repeat until all four poles are assembled.


Insert four complete poles, one at a time, into the side channels on the inside of the teepee canvas. Ensure the wooden poles (B) with hole are at the top. Slide each pole right to the base of the canvas channel.

# 3



Attach wood poles together using the cotton string at the top of the canvas. Lie the teepee flat and bunch the ends together. Thread the string through the holes in the pole, alternating each time (keeping all poles bunched together). Tie the ends of the string together securely.

# 4



All done! Ensure all teepee poles are fully extended and the fabric in each section is taught. The fabric should not sag between poles if all poles are fully extended. Enjoy!